

Code

BC.510**Pentola digitale a cottura lenta****Digital Slow Cooker****280W****4,5L****3
COOKING
FUNCTIONS****30MIN/
16H
TIMER****STAINLESS
STEEL**

- Display digitale e 3 impostazioni di cottura predefinite
- Timer di cottura da 30 minuti a 16 ore
- Funzione per ritardare l'accensione da 30 minuti a 16 ore
- Funzione mantenimento in caldo automatica a fine cottura
- Recipiente da 4,5 litri in ceramica antiaderente, lavabile in lavastoviglie
- Coperchio in vetro per controllare la cottura
- Basso consumo energetico
- Digital display and 3 pre-set cooking settings
- Cooking timer from 30 minutes to 16 hours
- Delayed start from 30 minutes to 16 hours
- Automatic "keep warm" function at the end of cooking to keep food warm
- 4.5 liter non-stick ceramic bowl, removable and dishwasher safe
- Glass lid to control cooking
- Low energy consumption



8 056420 220902

PRODUCT (LxWxH)	GIFT BOX WEIGHT	GIFT BOX (LxWxH)	CARTON PCS	CARTON WEIGHT	CARTON (LxWxH)	PCS EPAL
37x27,5x25,5 cm	5,2 Kg	38x31x23,5 cm	2	11,4 Kg	63x39,5x26 cm	40