

Code

P101CUD200**Fontana di cioccolato****Chocolate Fountain****90W****750ml****3
SETTINGS****OFF****HEATING****FOUNTAIN**

- Crea una bellissima cascata di cioccolato
- Movimento continuo del cioccolato fuso mantenuto a una temperatura costante
- Ideale per immergere vari tipi di frutta fresca, frutta candita, biscotti, waffle, churros, marshmallows
- Adatta per tutte le gradazioni di cioccolato
- Torre in acciaio inox a 3 livelli, rimovibile per una facile pulizia
- Tre impostazioni: off, riscalda e fontana

- Creates a beautiful chocolate waterfall
- Continuous movement of the melted chocolate maintained at a constant temperature
- Ideal for dipping various types of fresh fruit, candied fruit, cookies, waffles, churros, marshmallows
- Suitable for all chocolate grades
- 3-tier stainless steel tower, removable for easy cleaning
- Three settings: off, heat and fountain



8 056420 223200

PRODUCT (LxWxH)	GIFT BOX WEIGHT	GIFT BOX (LxWxH)	CARTON PCS	CARTON WEIGHT	CARTON (LxWxH)	PCS EPAL
15,5x16,5x31,5 cm	1,5 Kg	19x18x32 cm	4	5,2 Kg	39x37,5x34 cm	120